Installation Guide




Connection of AV Adapter and Controller Cable

Hold the cable, align the side of jack marked with ⇒ on the female 13-pin connector with the male 13-pin connector marked with ⇔ then firmly plug together.

- ① Black 4 pin male for Camera1.
- ② Black 4 pin male for Camera 2.
- 3 Black 4 pin male for Camera 3.
- Single red wire for power wire of DC / 12-32V.
- Single black wire for GND.
- Single brown wire to positive power wire of the back-up light.
- Single white wire to positive power wire of left Light.
- Single blue wire to positive power wire of right light.







Black 4 pin male for Camera 1 / Camera 2 / Camera 3. Single red wire for positive power supply of DC / 12-32V. Single black wire for GND.

Single brown wire to positive power wire of back-up light.
Single white wire to positive power wire of left turn light.

Single blue wire to positive power wire of right turn light.

